



# CREATOR PRO IV

 	<b>Program Instruction and Setup Manual</b>	
	<p><b>ÖSTLING</b> Technologies</p> <p>931 East Water Street Chillicothe, Ohio 45601 - USA</p> <p>TEL.: 1 740 779 9918 FAX: 1 740 779 9910</p> <p><a href="http://www.permanentmarking.com">www.permanentmarking.com</a></p> <p>Printed: 27.11.2002</p>	

*Lasonall*  
**MARKER**  
**CREATOR PRO IV**

**Published on: 26.11.02**

## Updates

[illegible]

Microsoft, MS, MS-DOS, Windows 98, Windows NT, Visual Basic, PowerPoint, Microsoft Press, are registered or trademarks of Microsoft Corporation In the United States or other countries.

Pentium® is a registered trademark of Intel Inc.

TrueType is a registered trademark of Apple Computer, Inc.

The information contained in this present document is subject to change without prior notice. All product or program names mentioned in this document are registered trademarks owned by the respective companies. They are only used in this document for editorial purposes.

Table Of Contents .....	3
<b>CHAPTER 1 INTRODUCTION.....</b>	<b>7</b>
System requirements for Creator Pro IV .....	8
Creator Pro IV Installation .....	8
Selecting the language.....	9
Creator Pro IV Innovations .....	10
Engraving project.....	10
VB Script.....	10
Simulation.....	10
Grid.....	10
Clone.....	11
Connected objects (LDC format).....	11
Main differences between Creator Pro IV and the previous release.....	11
<b>CHAPTER 2 BASIC CONCEPTS.....</b>	<b>13</b>
Overview.....	14
Creating a new project.....	15
Creating a new project for plane engraving.....	16
Focus length.....	17
Creating a new project for ring work engraving.....	18
Drawing with Creator Pro IV .....	19
Importing graphics with Creator Pro IV .....	20
Information on bitmap and vectorial graphics.....	21
Vectorial graphics.....	21
Bitmap graphics .....	22
Creator Pro IV work environment.....	23
Zooming reducing .....	23
Property window .....	24
Project property.....	24
Engraving document property.....	24
Graphic object property .....	27
Setting the measurement unit .....	27
Coloring of graphic objects .....	28
<b>CHAPTER 3 CREATING GRAPHICS.....</b>	<b>29</b>
Creator Pro IV drawing tools .....	30
Imported graphics .....	30
LDC connected objects.....	30
Creator Pro IV objects .....	30
Using the text tool .....	31
Special character sequences.....	32
Example of date in dd/mm/yyyy format .....	32
Example of date in dd/mm/yy format .....	32
Example of counter.....	33
Selecting text properties.....	34
Adding a bar code .....	38
Terminology .....	38
Classifications.....	39
Structure of a bar code symbol .....	40
Selecting bar code properties .....	41
Creating a Data Matrix.....	44
Terminology .....	44
Selecting Data Matrix properties .....	45
Deleting.....	48
<b>CHAPTER 4 IMPORTING IMAGES.....</b>	<b>49</b>
Adding images to CREATOR PRO IV .....	50
Importing vectorial graphics .....	50
Setting vectorial image parameters .....	51
Importing Bitmap graphics .....	52
Setting Bitmap image parameters .....	53

## Chapter 1

Operators .....	101
Conditional Structures .....	102
Structures for cycles.....	104
Objects .....	106
Creator Pro IV Active Objects .....	106
Examples of VBScript .....	111
<b>CHAPTER 10 CUSTOMIZING CREATOR PRO IV .....</b>	<b>113</b>
Origin of the work area .....	114
Moving the origin of a work area.....	114
Installing new fonts .....	115
Setting the focus.....	116
<i>Mechanical Axis Management</i> .....	117
Linear axes .....	117
Rotary axis .....	117
<i>Connecting an axis (Step Controller)</i> .....	118
<b>CHAPTER 11 DSP BOARD MANAGEMENT .....</b>	<b>119</b>
<i>Laser Control</i> .....	120
"Scanner" parameters .....	120
"Laser" parameters .....	121
"Correction" parameters .....	122
"Limits" parameters .....	123
"Inputs" parameters .....	124
"Outputs" parameters .....	125
"X/Y/Z Axe" parameters .....	126
<b>CHAPTER 12 ENGRAVING AND OPTICAL CORRECTION.....</b>	<b>127</b>
<i>Foundations of engraving and optical correction</i> .....	128
Distortion .....	128
Barrel distortion .....	129
<b>CHAPTER 13 PRACTICE EXERCISES .....</b>	<b>131</b>
Exercise 1 -Project for engraving on different levels .....	132
<b>CHAPTER 14 END USER LICENSE AGREEMENT .....</b>	<b>135</b>
Important - Read carefully: .....	136
Software product license.....	136
1. Grant of license .....	136
Software.....	136
Storage/Network use.....	136
License package.....	136
2. Description of other rights and limitations .....	136
Limitations on reverse engineering, decompilation and disassembly. ....	136
Separation of components.....	136
Rental.....	137
Software transfer.....	137
Termination.....	137
3. Upgrades .....	137
4. Copyright .....	137
5. Dual-media software .....	137
6. Warranty conditions.....	138
Limits of the warranty.....	138
Customers' rights. ....	138
Warranty exclusions.....	138
Exclusion of liability for indirect damages. ....	138



# Introduction

ÖSTLING Creator Pro IV, is an application program for the graphic creation of two dimensional objects for engraving with ÖSTLING laser



For management of external signals, controlling and entering engraving data using Creator Pro IV, **it is necessary** to install and configure the DSP interface board. See the DSP Installation Guide.

## System requirements for Creator Pro IV

- For Microsoft Windows™: 300 MHz Intel Pentium® processor or equivalent (433 MHz recommended) with Windows NT4, Windows 2000, or Windows XP), 64 MB RAM (128 MB recommended), 40 MB space available on hard disk, color monitor which supports 800 x 600 resolution and CD-ROM drive.



**NOTE:**

Creator Pro IV can also be installed on Windows 98 but its functionality is limited to **emulating** and **not engraving**.

- If laser engraving is to be performed, a ÖSTLING DSP board with proper driver must be installed.

## Creator Pro IV Installation

The Creator Pro IV program must be installed on a PC with 800 x 600 or higher resolution color monitor.

Follow this procedure to install Creator Pro IV on your Windows computer:

- Insert the Creator Pro IV CD in the computer CD-ROM drive
- Carry out one of the described operations:
- In Windows,  
Wait for the CD auto run if it is active  
select Start > Run. Click on Browse and select the Setup.exe file on the Creator Pro IV CD. Click on OK in the Run window to start the installation.
- Follow the prompts on the screen.
- If necessary, reboot the computer.

## Selecting the language

The guided installation program installs Creator Pro IV and related applications. One of these applications is called LOCALIZE, and allows users to choose the language for Creator Pro IV and Laser Control.

Select (Windows) Start > Programs > Lasonall Creator IV > Localize

Or select directory `..\Lasonall Creator IV\bin` and open the executable: `LaserLocalize.exe`

The program is configured to detect the language of the operating system and adapt as necessary. To set a specific language, select it using the Localize program. The following window will appear when the program is started:



Creator Pro IV is the development of previous versions of Creator.

Creator Pro IV also includes expanded functions for the creation of actions with Script in Visual Basic, integrating the Active Script technology.

Please see the “VB Script” chapter in this manual.

The work flow of Creator Pro IV has been greatly streamlined thanks to the introduction of a "project" concept.

In addition to the already known modes present in the previous Creator including Vectorial Work and Ring Work (which have been maintained) a new mode has been introduced: the engraving project.

The engraving project is able to group: vectorial objects, Bitmaps, and engraving on rotating axes; in addition mechanical axe movements and activation from external signals can be associated to each object. Input and output signal logic control makes it possible for a flexible and versatile organization of the project which can be compared to elementary PLC functions.



Creator Pro IV maintains complete compatibility with previous versions of Creator. The files generated with the previous versions can be used by Creator Pro IV. Files generated with Creator Pro IV cannot be used with the previous versions of Creator.

Creator Pro IV makes it possible to enter particular functions associated to individual project elements. The entire group of some function examples are included in the standard version of Creator Pro IV and make it possible for example to

- Manage work shifts
- Manage special characters to be associated to the current date
- Manage serial communication
- Etc.

The functions are activated in the properties window. Existing scripts may be selected or new ones may be created. Setting new functions requires experience with Visual Basic programming.

A graphic project to be used for engraving can be simulated. Thus there is a command which displays the format that the laser will execute in the engraving area.

The grid is a new instrument which simplifies the placement of objects on Creator Pro's graphic area, making placement of objects on the drawing faster and more precise.





---

## **Chapter 2**


### **Basic Concepts**

## Overview

The Creator Pro IV program makes it possible to generate graphic files and translate them into paths for laser engraving. The laser engraving system consists of:

- 1) DSP board to be connected to a standard or industrial PC slot
- 2) DSP board driver.
- 3) DSP control program for tuning engraving parameters.
- 4) Graphic editor for drawing models to be sent to the engraver..

The complete system components hierarchy is illustrated in the following chart



The engraving file is graphically created by **Creator Pro IV**, a program for creating bitmap models, photographic marking and vectorial models, consisting of:

- Text strings.
- Customized date and time.
- Counter.
- Barcodes.
- Data matrix.
- Vectorial Drawings (VCT, PLT, DXF).
- Bitmap Drawings (BMP, JPG, GIF)

The DSP board program manages up to three linear mechanical axes and one rotating mechanical axe.


Creator Pro IV can be used to create graphic models for laser engraving with ÖSTLING DSP engraving systems. The program has two separate operating modes:

- **Work mode.** This mode is for working only. In other words, the loaded model cannot be edited in any way. In this mode, the program automatically updates the "active" components (for example the date or the counter) at each engraving job beginning and end..  
The work mode can be blocked by a password.
- **Edit mode.** This mode is used for creating/editing vectorial graph models (text strings, bar codes, data matrix, CAD files, etc.) and bitmap models (Windows BMP) and either sending the models to the engraver or saving them on the disk.

## Creating a new project

When creating a new work, with Creator Pro IV the type of work to be effected is set from a selection window.

To create a new work select File> New.



After selecting the command, specify the type of work using the related icon.

### Existing file

Use this command to open an existing file

## Plain

Use this command for creating a new engraving file for flat surfaces

## Ring

Use this command to create a new engraving file on a rotating axis

## Bitmap

Use this command to create a new bitmap engraving file

## Sequence

Use this command to generate a series of graphics to be engraved in sequence

## Collection

Use this command to generate a series of graphics to be engraved by remote command

## Project

Use this command to generate an engraving project. The engraving project is able to group vectorial, Bitmap, and rotating axe engraving, in addition for each object it is possible to associate movements of mechanical axes and activation from remote signals, Input and output logic signal control.

## Creating a new project for plane engraving


When working with Creator Pro IV, a project is created composed of new graphic forms for engraving and organized with any elementary functions for completing the activity required by the application. Creating or editing a project is only from:

- Mode > work mode

To create a new project to use for engraving a flat surface:

- Select File > New
- Select Plain from the window
- A new window "1" will open corresponding to the laser engraving model

In work window 1 it is possible to draw the graphic to be engraved or import a drawing if the extension is compatible with Creator Pro IV (DXF, PLT, BMP), see the chapter on exporting files for additional information.



- 1 Work area.
- 2 Tool bar with tools for drawing and managing the project.
- 3 Menu with all Creator Pro IV commands.
- 4 Property window. This changes depending on the type of operation required.
- 5 Project pages. See relative chapter.



**NOTE:**

The size of the work area is a fundamental parameter. The maximum size that can be used is based on the focus height installed on the engraving laser.



## Creating a new project for ring work engraving


As previously described for plane surface engraving, when working with Creator Pro IV a project is created composed of new graphic forms for engraving and organized with any elementary functions for completing the activity required by the application. Creating and editing a project is only from:

- Mode > edit mode

## To create a new project for rotary axis engraving

- Select File > New
- Select Ring from the window
- A new window "1" will open corresponding to the laser engraving model

In work window 1 it is possible to draw the graphic to be engraved or import a drawing if the extension is compatible with Creator Pro IV (DXF, PLT, BMP), see the chapter on exporting files for additional information.



1. Model with preset size based on the linear development of the surface to engrave.
2. Tool bar with tools for drawing and managing the project.
3. Menu with all Creator Pro IV commands.
4. Property window. This changes depending on the type of operation required.
5. Project page, TAB. See relative chapter.



**NOTE:**

The height and diameter of the work area is a fundamental parameter. The displayed work area is the development of the surface to be engraved.


## Drawing with Creator Pro IV

Two dimensional graphics generated by other programs (Autocad, Corel, Macromedia, Adobe...) can be imported in the Creator model.

The following are Creator Pro IV importation files:

- **DXF:** is a two dimensional vectorial graphic exchange format primarily used by CAD applications, but available for most vectorial graphic applications on the market.
- **PLT:** is a vectorial format used as an exchange file for plotters. The filters that are equipped with vectorial graphic programs can be used to generate it, or by installing HP model 7475A plotter in the operating system and printing the graphic created with the application on the file.
- **BMP:** is the standard format for bitmap graphics. It can be generated with any graphic application, from digital cameras or scanners.
- **DIB: Device Independent Bitmap**, is a format similar to BMP. It can be generated with any graphic application, from digital cameras or scanners.
- **JPG:** is one of the most common compressed bitmap formats. A BMP image converted into JPG has a much smaller (in bytes) dimension, it is generally used in continuous tone images.
- **GIF:** is a format similar to BMP. It can be generated with any graphic application, from digital cameras or scanners.
- **VCT:** engraving graphics generated by Creator (2.11 or lower)

The imported graphic can be located in the model and moved, re-dimensioned, rotated and transformed so that it is compatible with the object to be engraved.



The example in the figure shows a drawing imported into a Creator Pro IV model and then re-dimensioned and rotated to adapt it to the object to be engraved.


## Importing graphics with Creator Pro IV

After having created a new project as described in the previous chapters, it is possible to import a drawing as follows:

- Select: Actions > Add > Import File

The following window will be displayed

- Select the importation filter from the "File type" combo box.
- Specify the path of the file to be imported from the "search" combo box.
- Select the file.



After having positioned the file inside the work area, elementary operations can be effected, for example:

- positioning the object on established coordinates
- changing the height and width of the object
- filling the object with filler lines (only if the lines of the imported object are closed)

The drawing can be completed by adding other imported graphics or with Creator Pro IV entities, for example:

- Text strings
- Bar codes
- Data matrix
- Connected objects (LDC)



**NOTE:**

The use of LDC connected objects is described in the following chapters.


## Information on bitmap and vectorial graphics

Computers display vectorial or bitmap graphic formats. Understanding the difference between the two can be helpful for working more efficiently.

Creator Pro IV is able to generate and import two dimensional vectorial graphics and also import and edit bitmap graphics created in other applications.

## Vectorial graphics


Vectorial graphics describe the images using lines and curves, called vectors, which all include properties related to color and position. For example the image of a feather is described by points through which lines pass, creating the form of the outline of a leaf. The color of the leaf is determined by the color of the outline and the color enclosed within the outline. In the example described below a black and white feather is represented because the laser engraving is monochromatic. When vectorial graphics are edited, all the properties of the lines and curves which describe the form are also edited. It is possible to move, re-dimension, remodel and change the color of vectorial graphics without changing their quality. Vectorial graphics are not resolution dependent, this means they can be displayed on output devices with different resolutions with no change in quality.



In laser engraving a vectorial graphic is faster in engraving and more defined in terms of outline lines and filling. A vectorial graphic cannot be used for engraving digital photographs.

Bitmap graphics describe images using colored dots, called Pixels, located within a grid. For example, the image of a feather is described by the specific position and color of every pixel in the grid, the creation process is very similar to that of a mosaic.

When bitmap graphics are edited the pixels are edited instead of the lines and curves. The bitmap graphics change with resolution, as the data which describes the image is fixed in a grid with specific dimensions. Editing bitmap graphics can change their quality. In particular, re-dimensioning bitmap graphics may make the edges of the image irregular since the pixels within the grid are redistributed. In addition, displaying bitmap graphics on an output device with a lower resolution in relation to the image reduces the display quality.



## Creator Pro IV work environment

During the creation and editing of projects for engraving, normally the following key functions are used

- The graphic work area where the drawing is represented
- The project work area where any sequences and functions are displayed within the individual project
- Property window, where the engraving parameters and properties for the single graphic objects are set
- Simulation for displaying a new window with the outline of what the laser is going to effect in the engraving area
- The toolbar for editing the various project and drawing elements..

## Zooming reducing

By changing the zoom, it is possible to display the whole graphic area on the screen or a greatly enlarged detail of a particular part. The maximum zoom depends on the screen resolution and the dimensions of the graphic area.


The zoom or reduce use the following techniques:

- To zoom a certain element, select the Zoom tool and click on the element.
- To zoom a specific area in the drawing, use the zoom to trace a rectangular window around the perimeter. Creator Pro IV sets the zoom level so that the specific rectangle fills the window..
- Or select Zoom > Window
- To zoom or reduce the entire window, select Zoom > In or Zoom > Out.





The characteristics for graphic objects to be engraved on rotating axes are set on the "Ring Work" page.


General		Ring Work		Laser	
Standard Parameters					
Diameter	10				
Height	10				
Margin	1				
Engave	Outside 				
Print Area					
Width	31.4159				
Height	110				
Advanced Sets					
Sector Size	0				
Angle	0				
Reset axis at t...	<input type="checkbox"/>				
Use ring radiu...	<input type="checkbox"/>				
Ring Z Position					
Enable	<input type="checkbox"/>				

## Standard Parameters

Diameter:	The size of the external or internal diameter, expressed in millimeters.
Height:	The height of the ring or cylinder, expressed in millimeters
Margins:	Sets the width of the margins in the work area
Engrave :	Sets engraving inside or outside the ring

## Advanced Sets

**Sector Size:** Defines the width of the sector in millimeters, The sector represents a graphic portion to be engraved. When sector is 0, each element is engraved individually, and after each element, the motor of the separator advances. If the sector value is greater than 0 (set according to the size of the part), engraving will be organized by sectors. This will reduce the number of motor movements.





Angle


Reset axes at engraving end

Use radius as Z position:  
be

Creator Pro IV can be used to automatically focus the ring to

the

For correct operation of this option, set the logic zero of axis Z in the revolution center. Logic zero is the focus position on the item to be engraved.



### Position Z

### Enable/Height

The R axe value. It can be edited using "Enable", set the new value in "Height"

### Graphic object property

Each object that makes up the model can be edited using the mouse, toolbar or "property window" which displays all the characteristic parameters including: sizes, origins, filling, laser parameters etc. It is important to note that also the document itself is an object which properties can be accessed when no other object is selected. Each graphic object uses by default the laser parameters of the document. You can set different laser parameters for each object, in this case, the parameters will appear blue.


Object properties depend on the selected object, this is discussed in the paragraphs related to individual graphics (text, bar codes and data matrix).

## Setting the measurement unit

Creator Pro IV makes it possible to set the linear measurement unit which characterizes part of the configurations. You can use the "General" page located in the project property window and set the measurement unit in millimeters or inches from the "Measurement unit" menu.

Resolutions	
Linear	0.01
Angle	1
Relative	5

Measure Units	
Linear	[mm] 
Project	[mm] [inch]
Enable	<input type="checkbox"/>

### **Resolution**

Linear Represents the approximation for linear quotes. Each entered measurement unit will be approximated to the value set in this box

Angle Represents the approximation for angle quotes. Each entered measurement unit in degrees will be approximated to the value set in this box

Relative Represents the approximation for relatives, that is expressed in percentages. Each entered percentage value will be approximated to the value set in this box.

The objects in the graphic area may be different colors.

- NOTE:**

The screenshot shows the LaserCAD software interface. The main workspace displays a 10x10 grid with the following text elements:

- GREY**: Text in grey color, located in the upper-left quadrant of the grid.
- RED**: Text in red color, located in the middle-left quadrant of the grid.
- BLACK**: Text in black color, located in the center of the grid.
- BLUE**: Text in blue color, located in the lower-left quadrant of the grid.

The right-hand panel shows the 'General' tab with the following properties for the selected object:

General	
Name	
Enable	<input checked="" type="checkbox"/>
Position X	-70
Position Y	45
Width	10.5
Height	4
Maintain Aspect	<input type="checkbox"/>
Angle	0
Shear X	0
Shear Y	0
Origin	
Position	Center

---

## **Chapter 3**

### Creating Graphics

## Creator Pro IV drawing tools

Creator Pro IV drawing tools can be divided into two different types:

- Imported graphics
- LDC connected objects
- Creator Pro IV objects

## Imported graphics

For a description and the use of imported graphics see the description contained in the previous chapter.


### LDC connected objects

For a description and the use of LDC connected objects see the description contained in the previous chapter.

## Creator Pro IV objects

Some elementary forms able to complete the engraving can be introduced into the graphic area.

- Text
- Bar Code
- Data Matrix



It is possible to insert text boxes in the projects destined for user input or dynamically displaying updated texts, by associating an identification to a string.

It is also possible to place the text inside or outside of a circumference arc.

To add a text string in Creator Pro IV:

- Font style
- Character height
- Compression percentage
- Spacing percentage
- Character angle
- Character shear
- Circle arrangement arc radius
- String ID

The text string can contain any alphanumeric character and one or more of the following special character sequences:

%a, %A	: Day of the week, abbreviated (a) or full (A)
%b, %B	: Month of the year abbreviated (b) or full (B).
%c	: Date and time according to current location
%d	: Day of the month, decimal number (01 –31)
%H	: Time 24 hour clock format (00 – 23)
%I	: Time 12 hour clock format (01 – 12)
%j	: Day of the year, decimal number (001 – 366)
%m	: Month of the year, decimal number (01 – 12)
%M	: Minutes, decimal number (00 – 59)
%p	: A.M. / P.M. indicator
%S	: Seconds, decimal number (00 – 59)
%U	: Week of the year, decimal number (00 – 51, Sunday is the first day of the week).
%w	: Day of the week, decimal number (0 – 6, Sunday = 0)
%W	: Week of the year, decimal number (00 – 51, Monday is the first day of the week).
%x	: Date according to current location
%X	: Time according to current location
%y	: Year, two digit decimal number (00 – 99)
%Y	: Year, four digit decimal number
%z, %Z	: Time zone, name (Z) or abbreviation (z).
%n	: Counter, decimal format
%o	: Counter, octave format.
%e, %E	: Counter, hexadecimal format, lower case (e) or upper case (E)
%s	: Data from serial RS232-C.
%%	: Percentage sign%
%ID	: (Percentage sign followed by an ID number) ID number string copy

### Example of date in dd/mm/yyyy format

- Create a text string.
- Select the required parameters (font, character height etc.)
- Enter the string "%d/%m/%Y" in the text box and press enter

- Create a text string.
- Select the required parameters (font, character height etc.)
- Enter the string “%d/%m/%y” in the text box and press enter




The property window displays the text parameters only when the text in the graphic area is selected. Typical text parameters are shown on the various pages in the figure.

**General:**

**Main:**

Enable:	Enables engraving of the selected text (if not enabled the text is gray)
Position XY	Sets the text coordinates in relation to the origin of the engraving area (0,0 is the center of the area)
Width, Height:	Sets the text width, height
Maintain Aspect:	If enabled, keeps the proportions between width and height
Angle	Sets the rotation angle (in degrees) of the string on the engraving area
Shear X	Sets a shear on axis X. The shear in the figure on the right is 50.

Shear Y      Sets a shear on axis Y. The shear in the figure on the right is 50.



**Origin:**

Position	This is used to move the reference origin of the string. The origin is identified by an X placed in the center, this can be moved to one of the four corners of the selected object.
----------	--



**Filling:**

Fill type...	Use to fill a text string. Filling is effected with parallel lines.
Fill angle...	Represents the fill angle
Fill space...	Represents the fill line space
Not engrave path:	If this option is selected, only filling lines will be engraved.

General	String	Data	Laser
<b>Main</b>			
Enable			<input checked="" type="checkbox"/>
Position X		0	
Position Y		0	
Width		22	
Height		10	
Mainaint Aspect			<input type="checkbox"/>
Angle		0	
Shear X		0	
Shear Y		0	
<b>Origin</b>			
Position		Center	<input type="button" value="v"/>
<b>Fill</b>			
Fill Type		Unidirectional	<input type="button" value="v"/>
Fill Angle		0	
Fill Space		0.1	
Not Engave Path			<input checked="" type="checkbox"/>
<b>Clone Object</b>			
Enable			<input checked="" type="checkbox"/>
<b>Number of clones</b>			
Clones in X		0	
Clones in Y		0	
<b>Offset of clones</b>			
Offset X		0	
Offset Y		0	

# String String

Enable	This is enabled in order to generate clones of the selected object. Clones are objects which are identical to the original one, placed on a rectangular matrix. Editing of the original object parameters (in black) is reflected on its clones (in green)
Clone in X	Represents the number of clones on the horizontal axis (X)
Clone in Y	Represents the number of clones on the vertical axis (Y)
Offset X	Represents the offset of the clones on the X axis in relation to the original
Offset Y	Represents the offset of the clones on the Y axis in relation to the original





### **Main data**


Text:	Enter the string to be engraved in the TEXT field; or the value of the variable which represents it
ID:	Represents the numeric value which univocally identifies the object in the document

Start: minimum value of the counter.  
 Stop: maximum value of the counter.  
 Step: value of the increment (positive or negative)..  
 Cycles: number of engraving jobs required to increase the counter.  
 Digits: minimum number of digits to be displayed.



### Customized formatting

**Enable:** Enables management of VB script (see relative chapter)



## Terminology

<b>Bar code</b>	A succession of alternating dark elements (bars) and blank elements (spaces) Code may also mean the type of coding.
<b>Element</b>	Name of a space or a bar
<b>Bar</b>	Dark element of a code
<b>Space</b>	Blank element between two bars
<b>Bar code symbol</b>	A complete bar code, made of a blank area before the code, a start character, one or more characters containing the information, a stop character and a final blank area.
<b>Discrete code</b>	Bar code in which all elements are not significant. Some act as separators, relatively broad tolerances are allowed for their thickness.
<b>Continual code</b>	The bars and spaces which contain information.
<b>Inter-character space</b>	A space which separates two adjacent characters, in some codes (code 39, bar code) the spaces inside a character contain information, inter-character spaces do not.
<b>Module</b>	The smallest thickness in a code element. It constitutes the measurement unit of the thickness of wide elements.
<b>Character</b>	Succession of bars and spaces which code a single decimal digit or a special alphabet character.
<b>Start/Stop Character</b>	Each symbol starts with a start character and stops with a stop character. They are used to identify the type of code and indicate the reading direction
<b>Quiet Zone</b>	The blank spaces immediately preceding the start character and following the stop character.
<b>Print ratio</b>	In two thickness codes, it is the ratio between the thickness of the wide element and that of the narrow one














A Data Matrix can be represented as a dark drawing on a light surface or vice versa.

## Pattern



Represents the code of the string which is placed inside the pattern.

It is a single cell, it represents a bit in the code representation. It is represented by a square

Represents the type of encoding used by Data Matrix. Creator Pro IV uses the ECC 200 standard protocol (Reed Solomon Error Correction)

The following Data Matrix codes are available:

- C40
- TEXT
- ASCII
- X12
- EDIFACT
- BASE 256


The Data Matrix can be square or rectangular. The matrix dimensions can be automatic (based on the length of the string) or set by the user.

For square Data Matrix, the matrix ranges from a minimum of 10x10 to a maximum of 48x48. For rectangular Data Matrix the matrix ranges from a minimum of 18x8 to a maximum of 48x16.






**Reverse:** Data Matrix engraving can be reversed by enabling the relative tag (reverse). The figure below shows a normal Data Matrix (left) and a reversed Data Matrix (right).



Main Data	
Text	123456
ID	0
Counter	
Start	0
Stop	999
Current	0
Step	1
Cycles	1
Digits	3
Custom Formatters	
Enable	<input type="checkbox"/>

ID: Represents the numeric value which uniquely identifies the string or variable that represents the data matrix.

Start:	minimum value of the counter.
Stop:	maximum value of the counter.
Step:	value of the increment (positive or negative)..
Cycles:	number of engraving jobs required to increase the counter.
Digits:	minimum number of digits to be displayed.



**Enable:** Enables management of VB script (see relative chapter)



Or select the Eliminate command from the Actions menu.

---

## Chapter 4

### Importing images

## Adding images to CREATOR PRO IV

Bi-dimensional graphics generated by other programs (Autocad, Corel, Macromedia, Adobe...) can be imported into the Creator Pro IV work area. They can be composed of vectorial graphics or Bitmap.

## Importing vectorial graphics

The following vectorial graphics can be imported in Creator Pro IV:

- **DXF:** is a two dimensional vectorial graphic exchange format primarily used by CAD applications, but available for most vectorial graphic applications on the market.
- **PLT:** is a vectorial format used as an exchange file for plotters. The filters that are equipped with vectorial graphic programs can be used to generate it, or by installing HP model 7475A plotter in the operating system and printing the graphic created with the application on the file.
- **VCT:** engraving graphics generated by Creator (2.11 or lower)

To import a vectorial graphic into the work area:

- Select Actions > Add > Import
- Select the importation filter from the “File type” combo box.
- Specify the file path to be imported in the “search in” combo box
- Select the file.

After positioning the file in the work area, the object parameters can be set.



## Importing Bitmap graphics

The following Bitmap graphics can be imported in Creator Pro IV:

- **BMP:** is the standard format for bitmap graphics. It can be generated with any graphic application, from digital cameras or scanners
- **DIB: Device Independent Bitmap**, is a format similar to BMP. It can be generated with any graphic application, from digital cameras or scanners.
- **JPG:** is one of the most common compressed bitmap formats. A BMP image converted into JPG has a much smaller (in bytes) dimension, it is generally used in continuous tone images
- **GIF:** is a format similar to BMP. It can be generated with any graphic application, from digital cameras or scanners

To import a Bitmap graphic into the work area:

- Select Actions > Add > Import
- Select the importation filter from the “File type” combo box.
- Specify the file path to be imported in the “search in” combo box
- Select the file.

After positioning the file in the work area, the object parameters can be set.



## Bitmap

General		Bitmap	Laser
Data			
ID	0		
Adjust			
Brightness	0		
Contrast	0		
Resolution	300		
Reverse	<input type="checkbox"/>		
Video Modes			
Video Mode	Gray scale ▼		
	Gray scale		
	Monochrome		

### Adjust

**Brightness:** Used to adjust the brightness of an imported bitmap image  
**Contrast:** Used to adjust the contrast of an imported bitmap image  
**Resolution:** Used to change the resolution, expressed in dots per inch  
**Reverse:** Engraving of the imported bitmap can be done in reverse by enabling the relative tag (reverse).

### Video Modes

**Monochrome:** Converts the image to monochromatic  
**Gray scale:** Converts the image in dithering to gray tones


---

## **Chapter 5**

### Operations with objects

## Selecting objects

Selection of graphic objects is done by direct selection using the mouse cursor or by drawing a window which contains them. By drawing a window it is possible to select one or more objects, to select more than one object by direct selection, it is necessary to hold down the SHIFT key. The selected object is highlighted by a square, tools for changing the selected object are on the edges of the object. A small "x" marks the center of the selection perimeter.



To deselect an object, click on a blank area of the drawing window.

## Enabling/disabling an object

Each object in the graphic area can be disabled using the relative TAG, located in the properties window.

General   String   Data   Laser	
<b>Main</b>	
Enable	<input checked="" type="checkbox"/>
Position X	0
Position Y	0
Width	34
Height	13
Maintain Aspect	<input type="checkbox"/>
Angle	0
Shear X	0
Shear Y	0
<b>Origin</b>	
Position	Center ▾
<b>Fill</b>	
Fill Type	None ▾
<b>Clone Object</b>	
Enable	<input type="checkbox"/>

The "Enable" TAG disables the selected object. A disabled object is displayed in gray in the graphic area but will **NOT** be engraved.

## Group objects

The objects located in the graphic area can be batched so as to form a single object.

The functions `Batch`, `Separate` and `Intersect` of objects are used to create unusual and irregular shapes. They can be used on all objects. However it is not possible to batch or intersect bitmap pictures.

Batch, Separate and Intersect operations involve source objects and objective objects. For example to create a star cut-out on a square object, the star becomes the source object because it is used to cut the square. The square becomes the objective object because it is the one to be cut.



## Group

This command Group one or more objects in the work area. The single objects keep their structure, but the transformation and movement operations involve all of the batched objects. Groups containing strings can be used to change the text without prior separation.



## Ungroup

This is used to separate the objects combined with the batch function. The separated objects can then again be configured and transformed individually.



## Merge

is used to obtain an object with a single outline. It is possible to independently weld the objects even if they are overlaid. If objects are welded which are not overlaid, it is possible to form a welding group which acts as a single object. In both cases, the welded object assumes the filling and outline attributes of the objective object.

When single objects are welded with intersecting lines, the object is divided onto various sub-formats, while the aspect remains the same.


The cut-out creates new irregular shapes by removing the areas overlaying other objects. The objective object maintains the filling and outline attributes. For example, if a text is cut overlaying a circle the text area is removed, thus creating the effect of a reverse text.

Before cutting out the objects it is necessary to establish which object is going to be cut (objective object) and which objects to use in the cut-out. The objects used for the cut-out must be overlaying or be overlaid by the objective object.

The intersection creates a new object from an area where two or more objects overlay. The shape of this new object can be simple or complex, depending on the intersected shapes. The filling and outline attributes of the new object are based on the object set as the objective object.

# String

In the example below are represented three figure. The figure number one represent the vectorial imported graphics. The figure number 2 represent the same graphics but with filling lines. The figure number 3 represent again the same graphics, with filled lines but with merge functions enabled.



It is possible to position the objects by dragging them to a new location, using a shift operation, or by specifying the horizontal and vertical position.




The set values

To specify the position of an object, the horizontal and vertical coordinates to a central anchorage point of the object can be indicated or to another anchorage point. A small "x" marks the anchorage point.

For a per-set setting, the origin point (0,0) corresponds to the central point of the work area.

## Alignment of objects


Creator Pro IV can be used to align and distribute objects in the drawing. Alignment can be used to precisely align any series of objects. For example, it is possible, to align a series of objects horizontally or vertically.



### Reference object

Alignment operations for objects are characterized by a reference object. The reference object is the central point of the alignment and the selected objects move as a consequence.


The reference object can be identified by the black square apices. In the example below the reference object is the upper string. To change the reference object push the Control (CTRL) key and select a new one in the work area.



## Rotating and Mirroring Objects

Creator Pro IV can be used to rotate the objects and create mirror images. It is possible to rotate an object by specifying the angle "Angle" on the "General" page of the object properties.

It is also possible to change the rotation center "Position" in the same way, this is identified with a small "x" from the related menu in the property window.

General		String	Data	Laser
Main				
Enable	<input checked="" type="checkbox"/>			
Position X	0			
Position Y	10			
Width	34			
Height	13			
Mainaint Aspect	<input type="checkbox"/>			
Angle	0			
Shear X	0			
Shear Y	0			
Origin				
Position	Center 			
Fill	Left Bottom			
Fill Type	Left Top			
	Right Top			
	Right Bottom			
Clone Of	Center			
Enable	<input type="checkbox"/>			

Mirroring of the object is done by selecting **Actions > Mirror > horizontal (or vertical)**, or by using the keys on the tool bar.




### Mirror object along vertical axis



### Mirror objects along horizontal axis

In Creator Pro IV it is possible to shear and lengthen objects. To shear an object it is necessary to specify the value in degrees of required shear by specifying on the "general" page of the object properties the shear for axis X (shear X) and axis Y (shear Y). The same result can be obtained by dragging the relative apices after selecting the object.



ÖSTLING Markiersysteme GmbH

## Using the grid

The grid is a series of traced lines which intersect. They can be used to precisely align and position objects in the drawing window.

The distance between lines in the grid can be set by specifying the spacing in the document property window:

General > Snap to grid > Size

The "Size" spacing refers to the exact distance between each line, lower spacing values can be used to align and position objects with greater precision.

To display the grid in the drawing window the following tag needs to be enabled:

General > Snap to grid > Grid

To snap to grid objects the following tag needs to be enabled:

General > Snap to grid

Snap to is used to move objects and align them to the closest grid line.

General		Plain Work	Laser
Snap and Grid			
Snap To Grid	<input checked="" type="checkbox"/>		
Grid	<input checked="" type="checkbox"/>		
Size	10		
Origin			
Origin Position	Center	<input type="button" value="v"/>	



**NOTE:**

To display the document property window deselect each object in the drawing area.

---

## **Chapter 6**

### Project structure

## Project Structure

The project is a container which houses single graphic works and related functions. The following items may be located inside the project:



## Plain

This is a graphic work for plain engraving. By selecting Project > Add plain (or using the related icon) a work for plain engraving is added to the project, defined by the word PLAIN. Select the related pain to access the graphic area where it is possible to draw or import objects for plain engraving.



## Ring

This is a graphic work for ring engraving. By selecting Project > Add ring (or using the related icon), a work for ring engraving is added to the project, defined by the word RING. Select the related pain to access the graphic are where it is possible to draw or import. objects for engraving on the separator.



## Clone

This is a copy of a previously set Plain or Ring. The Clone function is related to the identification number of the original graphic work. Therefore the Plain or Ring to be cloned must have an ID number.



## Wait Start

This command interrupts execution of the project. Engraving is stopped at the end of the Plain or Ring prior to the Start wait. This period ends with a Start Engraving signal.



## Get and Go

This command is used to jump inside a project sequence. The conditions for effecting this function come from a reading of the signals on the Input ports. If the set condition occurs, the project will resume from the Plain or Ring defined by the corresponding ID. It is also possible to effect an unconditioned jump in the sequence.



## Set Out

This command is used to Set or Reset the output bits on the interface board.



## Move axis

This command is used to move the three mechanical axes (X, Y, Z) to the required position.



## Delete

Deletes the selected element.

The screenshot shows the SolidWorks software interface. On the left, the 'Project Root' tree is visible, containing a list of project items: Plain [01], Plain [03], Ring [05], Ring, Wait Start, Plain [08], Clone of -> [03], Set Out, Move Axis, and Get and Go at -> [05]. The 'Clone of -> [03]' item is highlighted. On the right, the 'Clone' table is displayed, showing the relationship between the cloned item and its source. The table has two columns: 'Text' and 'Clone of'. The row for 'Link ID' shows the value '03'. At the bottom, the breadcrumb path is shown as 'Project > Plain [01] > Plain [03] > Ring [05] > Ring > Plain [08]'. The status bar at the bottom indicates 'Ready'.

Clone	
Text	Clone of
ID	
Link ID	03

Project > Plain [01] > Plain [03] > Ring [05] > Ring > Plain [08]


Ready

---

## Chapter 6

## Project properties

When a new project is created some general parameters need to be specified. These parameters are located in the property window and are displayed by selecting the project that has just been created.

General		Project	
Resolutions			
Linear	0.01		
Angle	1		
Relative	5		
Measure Units			
Linear	[mm]		
Project Customization			
Enable	<input type="checkbox"/>		

General		Project	
Clone			
Text	Clone of		
ID			
Link ID	03		

The following parameters are set from the General Page:

## Resolution

Linear	Represents the approximation order for linear quotes. Every measurement unit that is entered will be approximated to the value set in this box
--------	--

Angle	Represents the approximation order for angle quotes. Every measurement unit that is entered will be approximated to the value set in this box
-------	---

Relative Represents the approximation order for relative, thus expressed in percentages.. Every percentage value that is entered will be approximated to the value set in this box

**Measurement unit**

**Linear** Sets the measurement unit used in the project

## Project Customization


Enables the use of VB script in the current project (see the related chapter)

The following parameters are set on the Project Page:

## Project

**Text** The name of the project can be set in this box


This is a graphic work for plain engraving. By selecting Project > Add plain (or using the related icon) a work for plain engraving is added to the project, defined by the word PLAIN. Select the related pain to access the graphic area where it is possible to draw or import objects for plain engraving.



The following parameters are set on the Project Page:

**Document**

Text	The name of a plain engraving work can be set in this box
ID	Sets an identification for a plain engraving work. Setting an ID is indispensable for enabling the Clone, Get and Go functions




The following parameters are set on the Project Page:

Text	The name of a ring engraving work can be set in this box
ID	Sets an identification for a ring engraving work. Setting an ID is indispensable for enabling the Clone, Get and Go functions

Some of the functions introduced to Creator Pro IV can be used to pilot I/O signals located on the Laser control board. This possibility is particularly useful if the laser system is installed in complex systems or long assembly lines. In these cases the control board can manage inputs and outputs in order to optimize system integration.

The electronics which control the laser system and the related I/O signals is composed of a board with DSP controller (laser controller) which is inserted in a PCI slot of a standard PC. Up to four expansion boards can be connected to this board to control I/O signals. The following figure represents a connection. Module 0 is always present, in addition to the I/O/ signals set by the application, it also controls the mechanical axes; the subsequent modules are optional and control the I/O signals set by the application.



## Control board I/O signals

I/O signals are located on the control board expansion boards. The connectors are described below. It is possible to increase the number of expansion boards and thus increase the number of available I/O.



**NOTE:**

The connectors 1 and 2 mounted on the Laser controller are reserved for the scanner head (connector 1) and for laser source signals (connector 2)

### I/O signals available on module 0

DB 25 pin male - Axis motor connection. The DSP board is able to generate the signals used to operate the three independent axes driven by step motors. All signals are of the open-collector type, i.e. are active in conduction (GND output) and not active with high impedance. All inputs are opto-isolated and require a voltage from 10 to 30 V to be activated.

Pin out	Pin out
1: +12V 500mA	14: +5V 500mA.
2: Reserved	15: Reserved
3: Reserved	16: Reserved
4: Reserved	17: Reserved
5: Reserved	18: Reserved
6: Reserved	19: Input 9.
7: Reserved	20: Input 8.
8: Reserved	21: Input 7.
9: Reserved	22: Input 6.
10: Reserved	23: N.C.
11: Reserved	24: N.C.
12: Reserved	25: GND.
13: GND.	

**NOTE:**



"Reserved" signals are use for axis control. For additional information see the DSP board manual. For this reason, some I/O addresses set on port 0 (module 0) will not be accepted by the program.

DB 15 pin male – Laser controls/status. The output signals of this connector are of the open-collector type, being active when conducting (output to GND) and not active when cut-off (high impedance). All inputs are opto-isolated and require a voltage from 10 to 30 V to be activated.

### Pin out

1:	Out – Laser End. Active at end of engraving.
2:	Out – Laser Busy. Active during engraving.
3:	Out – Laser Ready. Active when system is ready.
4:	In – External Start. Starts engraving when activated.
5:	In – External Stop. Stops engraving in progress when activated.
6:	Input 13
7:	Input 15.
8:	Output 15
9:	12V.
10:	DSP Ready
11:	N.C.
12:	GND
13:	Input 12
14:	Input 14
15:	Output 14

### Available I/O signals on Module 1 - 2 - 3

DB 25 pin male. Manages I/O signals set by the application. The signals are of the open-collector type for outputs, i.e. are active in conduction (GND output) and not active when cut-off (high impedance). The inputs are opto-isolated and require a voltage from 10 to 30V to be activated.

Pin out		Pin out	
1:	+12V 500mA	14:	N.U.
2:	Output 0	15:	Output 1
3:	Output 2	16:	Output 3
4:	Output 4	17:	Output 5
5:	Output 6	18:	Output 7
6:	Output 8	19:	Input 9.
7:	Input 0	20:	Input 8.
8:	Input 1	21:	Input 7.
9:	Input 2	22:	Input 6.
10:	Input 3	23:	Output 9
11:	Input 4	24:	N.U.
12:	Input 5	25:	GND.
13:	GND.		

DB 15 pin male. - Manages I/O signals set by the application. The signals are of the open-collector type for outputs, i.e. are active in conduction (GND output) and not active when cut-off (high impedance). The inputs are opto-isolated and require a voltage from 10 to 30V to be activated.

Pin out	
1:	Output 10
2:	Output 11
3:	Output 13
4:	Input 10
5:	Input 11
6:	Input 13
7:	Input 15.
8:	Output 15
9:	12V.
10:	Output 12
11:	N.C.
12:	GND
13:	Input 12
14:	Input 14
15:	Output 14



## Get and Go

This command is used to jump inside a project sequence. The conditions for effecting this function come from a reading of the signals on the Input ports. If the set condition occurs, the project will resume from the Plain or Ring defined by the corresponding ID. It is also possible to effect an unconditioned jump in the sequence.

This condition is defined as true when an AND condition between the port inputs and set mask are the same as the Value.

The parameters which set the Get and Go conditions are:

<b>Enable</b>	Enables the corresponding port (displayed based on the Installed Hardware)
<b>Mask</b>	Sets the bits to be compared with the state of the inputs
<b>Value</b>	Sets the value that establishes the true condition

General		Project
Get and Go		
Text	Get and Go at	
ID		
Ports		
1 - Enable	<input checked="" type="checkbox"/>	
Mask	D200	
Value	FFFF	
2 - Enable	<input checked="" type="checkbox"/>	
Mask	FFFF	
Value	FFFF	





This command is used to Set or Reset the output bits on the interface board.

The parameters which set the Configure Out condition are:

<b>Enable</b>	Enables the corresponding port (displayed based on the Installed Hardware)
---------------	--

**Output method** Sets the end of the function that can set the bits to 0 (reset) or to 1 (set)

<b>Value</b>	Sets the bit mask which the function will affect
--------------	--

General		Project	
Set Output			
Text	Set Out		
ID			
Ports			
1 - Enable	<input checked="" type="checkbox"/>		
Output Method	Set		
Value	F3C0		
2 - Enable	<input checked="" type="checkbox"/>		
Output Method	Set		
Value	Reset Set		



This command is used to move the three mechanical axes (X, Y, Z) to the required position.

The parameters which set the Axis Shift condition are:

General		Project	
Move			
Text		Move Axis	
ID			
Plain Z Position			
Axis X Enable		<input checked="" type="checkbox"/>	
Position X		0	
Axis Y Enable		<input checked="" type="checkbox"/>	
Position Y		0	
Axis Z Enable		<input checked="" type="checkbox"/>	
Position Z		0	

<b>Enable Axis Position</b>	Enables the corresponding mechanical axis (set based on the Installed Hardware) Coordinates positioning of the relative axis
-----------------------------	---

## LDC Files

Files generated in LDC mode are set as "connected" objects. They are generated by Creator Pro IV and can be imported in a graphic area or project.

The special feature of LDC files allows them to be imported in a project and dynamically updated.


When an LDC file is edited, its picture imported in the project is also edited. This possibility is very useful when graphic files need to be updated remotely, or at work stations which are not necessary those of the engraving laser.

## Creating LDC files

To create a LDC "connected" file apply the normal procedures for creating engraving projects described in the previous chapters. Creation of the graphic part is completely the same as that preciously described, to generate the LDC format the processed item needs to be saved using the command

File > Save Document.

Creator Pro IV will propose saving the document with LDC extension.



## Importing an LDC file

An LDC file needs to be imported in an existing project. To import an LDC file and thus generate a connection, select the command Actions > Add > Import File, select the Type of LDC file and confirm. The "Linked" page will appear in the property window.

General		Linked	Laser
Data			
ID	0		
Linked			
Enable	<input checked="" type="checkbox"/>		
Linked To	C:\WINDOW...		
Reload	Reload		

The Id of the imported object will appear on the "Data" page, and the following will appear on the "Linked" page

Enable	Enables a link with the LDC origin file, used to set the dynamic object
Linked to	Sets the path and position of the original LDC file
Reload	Press this button to update the link, any modifications made to the original LDC file will be replicated in the imported object



### NOTE:

If the LDC object is not enabled (using the relative tag), the object itself will be treated as a normal imported file.

---

## Chapter 7


### Laser

Creator Pro IV is able to manage up to three linear axes driven by a step motor.



### Axis Z

The program can be used for the integrated management of the Z axis (mechanical axis) for focusing on different levels. Either select Laser > Z axis or click "Z axis" on the toolbar to access the control window.



**Axis Z**

Zero flag	Detects the position of the mechanical axis (the Z axis is on the sensor)
Zero search	Enables a zero search along the Z axis, the zero position is related to a proximity
Minimum height	Sets the minimum height axis Z can reach
Maximum height	Sets the maximum height axis Z can reach
Current position	Indicates the current position reached by axis Z, may be an operator entered quote

### ***Laser Test***

These parameters are usually used during the focusing phase before engraving. See the related chapter for more information.

The axis control window is used to display the current position by means of a numeric indicator showing the current position in millimeters and a colored bar which graphically represents the axis position total offset. The axis can be positioned from the window by entering the new position in the specific box or by means of the "Up" and "Down" scroll buttons on the keyboard. In the latter case, press the button to start the movement and hold it pressed. The movement will be automatically stopped when the button is released.

The axis control function can also be used to reset, i.e. to automatically seek the mechanical reference position. Select "Reset". The axis will start searching. The search operation will stop when the mechanical zero sensor is reached.



**NOTE:**

Press the ESC key on the keyboard to stop any action (movement or reset).



### Axis XY

The program allows integrated management of the linear XY axes. These are mechanical axes used to position objects under the laser via step motor control. The axis control window can be accessed by selecting "Laser" → "Axis XY" from the menu or by pressing the "Axis XY" button on the toolbar.

**X-Y Axes commands**

Position

0.00

0.00

0.00

0.00

Laser test

**X Axis**

Zero Flag	<input type="checkbox"/>
Minimum X Positi...	0
Maximum X Posi...	0
Current X Position	

**Y Axis**

Zero Flag	<input type="checkbox"/>
Minimum Y Positi...	0
Maximum Y Posi...	0
Current Y Position	

**Common**

Zero Search	<input type="checkbox"/>
-------------	--------------------------

Ok

**Axis X**

Zero flag	Detects the position of the mechanical axis (the axe is on the sensor)
Minimum height axis X	Sets the minimum height axis X can reach
Maximum height axis X	Sets the maximum height axis X can reach
Current position axis X	Indicates the current position reached by axis X, may be an operator entered quote


**Axis Y**

Zero flag	Detects the position of the mechanical axis
Minimum height axis Y	Sets the minimum height axis Y can reach
Maximum height axis Y	Sets the maximum height axis Y can reach
Current position axis Y	Indicates the current position reached by axis Y, may be an operator entered quote

**Common**

Search for zero	Enables a search for zero along axis X and Y, the zero position is related to a proximity fixed on both axes.
-----------------	---

The program allows integrated management of the ring separator, indispensable for ring work engraving. The ring work control window is accessed by selecting "Laser" → "Ring work commands" from the menu or by pressing "ring work commands" button on the toolbar.



Numeric  
position  
indicator

Zero Flag	Detects the position of the mechanical axis (the rotor is on the sensor)
Zero search	Enables a zero search along ring R, the zero position is related to a proximity
Position axis R	Represents the indicator of the current position reached by axis R, it is expressed in degrees and can be entered by the operator

The ring control function can be used to reset, i.e. to automatically seek the mechanical reference position. Select "Reset". The axis will start searching. The search operation will stop when the mechanical zero sensor is reached.




Press the "ESC" button on the keyboard to stop any action (movement or reset).

## Limits

The term limits refers to displaying the margins of the drawing on the work plain. Margins are displayed using a red laser pointer (650 mm).

### Limits in the plain engraved area




Either select "Laser"→"Show selection limits" or click on the "Selection limits" button on the toolbar to display the engraving limits. In this way, you can see the pointer limits of the currently selected objects.

Either select "Laser"→"limits" or click on the "Limits" button on the toolbar to display the graphic object limits for the graphic area. In this way, you can see the pointer limits of the currently selected objects.

During limit display the area involved in engraving is shown and NOT the profile of the object to be engraved. The limits always describe an orthogonal area.

The example below shows how the limits for a sheared word (ÖSTLING) would appear.






## Project test

Creator Pro IV can be used to simulate an engraving result. It is possible to enable an Emulation mode using the button **E** located on the toolbar.

In this way, by pressing the icon represented by a yellow signal, which normally starts engraving, a new window opens in which engraving is simulated. The simulation maintains all the speed, filling, wobble etc. parameters set in the document.



### NOTE:

Simulation is automatically enabled if the DSP board and relative driver are not installed correctly.

## Document laser parameters

To configure identical laser parameters for all objects in a document, simply click any point of the work area so that **no object** is selected. The engraving properties for the entire document will appear on the Laser page.

- **Passages**  
This indicates the possibility of configuring more runs (up to 3) with differentiated laser parameters
- **Power**  
This indicates the laser output power. The value is a percentage according to the maximum power of the laser used.
- **Shot Frequency**  
This parameter is used to adjust the laser output frequency by directly operating on the Q-switch. The Q-switch is an electro-optical system which controls the opacity of a lens making it possible to change the laser beam frequency. A lower frequency will generate "spotted" engraving while a higher frequency will allow "line" engraving. Frequency is inversely proportional the laser beam power, i.e. if the frequency is too high, the power may not be sufficient for the engraving process. The Q-switch may be compared to a sluice shutter which closes and deflects the laser beam.
- **Scan Speed**  
This indicates the engraving speed. The value is expressed in mm

General		Plain Work		Laser	
Materials					
Material		Custom Mate			
Save		Save			
Delete		Delete			
Parameters					
Passages		1 passage		▼	
Passage - 1 -					
Power		67			
Shot Frequency		3500			
Scan Speed		200			
Pix Delay		1500			
Passes		1			
Wobble					
Enable		<input type="checkbox"/>			
Axis Position					
Axis Z Enable		<input type="checkbox"/>			
Laser Configuration					
Resolution		0			




a slower speed implies engraving a deeper engraving. Set a very slow speed (50-100 mm/sec.) for special processes (burnishing or deep engraving).

- **Pix delay**  
Duration of pixels for bitmap engraving
- **Passes**  
This indicates the number of runs required by the laser for engraving the imported objects. Increasing the number of passes will increase depth of engraving, consequently affecting the cycle time.



## Object laser parameters

The parameters set for the object can be different from those set for the entire document. Select the object and the Laser page to set the required parameters.




The edited object will appear blue.

Laser Creator Pro IV can be used to save different laser parameters in a Materials library. When engraving on different materials, the parameters can be saved by entering the material name in the box where the word **Materials** appears and pressing the **Save** button to save the parameters in the list.



The figure below represents the functioning principle of the wobble. Figure 1 shows the result of a vector engraving with the wobble disabled. Figure 2 shows the same vector but with the wobble enabled. The conversion of the vector into a dense spiral provides greater thickness of the engraved line. The same function can be applied to any vectorial graphic that is going to undergo plain or ring engraving.



<b>Ø Diameter:</b>	Represents the diameter of the spiral curve
<b>Speed:</b>	Represents the frequency of spiral repetition




The wobble function configuration parameters must be tested and checked in order to obtain the desired effect. Engraving times with the Wobble function are longer, only use the Wobble function when absolutely necessary.





Exiting from the work mode may be subject to a password.

To set a password select the Mode > Set Password command. In the following dialogue box set the password and confirm.





---

## **Chapter 8**

# **Engraving with Creator Pro IV**

## Focusing

Engraving in the conditions illustrated in the previous chapters implies that the laser head (see Lens) is at the correct focus distance from the item to be engraved.

The Z axis control window can be used to carry out "engraving tests" for focusing. The program sends a test to the laser which will continuously engrave a geometric shape with predefined parameters and position the axis at the same time. A greater interaction of the laser with the material under examination indicates that the optimal focus has been obtained.



**NOTE:**

The correct position can be identified as the engraving point in which the laser generated noise and luminosity are at the maximum.

To start the test, select the required geometrical shape (line, square or circle), set the dimensions in mm, set the laser parameters and enable the “Start Test” tag.



## Carrying out the engraving

To start engraving of the generated graphic file press the relative icon (yellow signal) or select the **Laser > Start** command.

The process can be stopped at any time during engraving by selecting "Laser" > "Stop" on the menu or by pressing the "Stop" button (red signal) on the toolbar.

## Setting waits

As previously illustrated, the engraving process is achieved by means of a laser beam deflection device controlled by two retroactive electrical drives (PID) which angular position is proportional to the control voltage provided. Due to the very nature of the system, the reaction time (phase) of the drives is not negligible. Consequently, the system generating the control signals (usually a PC) will need to wait for the positioning operation in progress to end before starting the next process.

## Calculating waits


The waiting times required for high quality engraving are illustrated below. Some waiting times are linear functions (linear phase) of the engraving speed and for this reason are parameterized by two variables, namely K: proportional coefficient for speed and C constant. The system computes the waiting time according to these two parameters with the following formula:

$$T = C + K \cdot \frac{\text{speed}}{\text{max speed}}$$

The speeds indicated in the formula are expressed in thousands of coordinates per second and the maximum reference speed mentioned in the formula is equal to 1000 [Kcoord/s], which corresponds to the following speeds expressed in [mm/s] according to the lens:

- $f_{100} = 1133.3 \text{ mm/s}$
- $f_{160} = 1822.2 \text{ mm/s}$
- $f_{254} = 2900.2 \text{ mm/s}$


The following example shows how to engrave the word "LASER":



these examples will better illustrate how incorrect technical waiting time setting effect the result.

## Tfirst

Waiting time for the scanner to actually reach the required position before switching the laser on.




If the delay is **lower** than the optimal value, notice how the first vector of each polygon is distorted and longer than the correct length..


If the delay is **higher** than the optimal value, the engraving process will be slower but no effects will be visible.

## Tnext

Waiting time for the scanner to reach the correct position before tracing the vector after the first with the exception of the last. This waiting time is according to the engraving speed and depends on the angle between the two consecutive vectors. If the angle is equal to  $180^\circ$ , the waiting time will be equal to zero, while the waiting time will increase as the angle decreases, the time being maximum when the angle is equal to zero degrees.




If the delay is **lower** than the optimal value notice how the polygon vectors are rounded and not sharp




If the delay is **higher** than the optimal value, notice how the polygon vectors are more marked and deeper than they should be.

## Tlast

Waiting time for the scanner to reach the correct position before switching the laser off (scanning the last vector of a polygon).




If the delay is **lower** than the optimal value, notice how the last polygon vectors are shorter and incomplete..




If the delay is **higher** than the optimal value, notice how the vector end points are more marked.

### Tdraw (Diode Laser)

Waiting time to allow actual laser emission before starting to scan the vector.




If the delay is **lower** than the optimal value, notice how the first vector of each polygon is shorter.



If the delay is **higher** than the optimal value, notice how the initial vector points are deeper.

## Tjump (Diode Laser)

Waiting time to allow the laser beam to actually go out before making a jump (scanning with laser off).



If the delay is **lower** than the optimal value, notice the blurring between the polygons.

If the delay is **higher** than the optimal value, the engraving process will be slower but no effects will be visible.

### Tramp / Ttresh (Diode Laser)

Waiting time (Tramp) for allowing the laser beam to stabilize before actually starting to engrave without holding the laser in the same position., i.e. without engraving the material which may be exposed to the undesired radiation. This wait is only carried out if the laser is off for a time which is higher than the threshold time (Ttresh).

## Bitmap - Toff

Waiting time for the scanners to reach a certain position before switching on the laser during bitmap picture engraving.

## Bitmap – Ton

Waiting time for adjusting the depth of each pixel during bitmap engraving. Essentially, this is the minimum firing time for each pixel.



---

## **Chapter 9**

### **VBScript**

## Information on VBScript

VBScript is a scripting language derived from Visual Basic, it is used to add customized functions to Creator Pro IV. VBScript is a object-oriented programming language. In object-oriented scripting the information is organized into groups called classes. It is possible to create more than one item in a class, called objects, to be used in the scripts. It is possible to use classes pre-set by VBScript or create customized ones.

When you create a class all the properties (characteristics) and all methods (behaviors) are set for each created object, just like setting objects in the real world. For example, a person is characterized by properties like sex, height, hair color and methods like how they talk, walk and throw. In this example, "person" is a class and each individual is an object or an item of the class.



**NOTE:**

The following paragraphs contain introductory information on the use of VBScript but it cannot be considered a complete guide. For further information, see the official programming manual.



## Variables

```
Dim variable1
Dim variable2
```

Or

Those who are used to other languages know that when a variable is stated the type also needs to be set, i.e. if it contains a number, a string, a date etc.

This distinction does not exist in VBScript: the variables do not have type. Management of a number or a string is entrusted to the VBScript interpreter. This makes it very easy to program, but you must be careful, as the following example shows:

In the example, I assign the values to variables a and b via InputBox, i.e. the dialogue box which asks the user to enter a value. If I assign the value 3 the first time and the value 5 the second time, one would expect the line "MsgBox c" to print the value 8 and instead it displays 35. This is because a and b are interpreted as strings and the + sign instead of adding, chains the 2 strings.

To solve the problem the variables must be converted from string to numeric using Eval (..).

Warning: types do not exist, but subtypes which characterize the variables do, they are:

<b>Boolean:</b>	Can contain True or False.
<b>Byte :</b>	Contains an integer between 0 and 255.
<b>Integer:</b>	Contains an integer between -32,768 and 32,767.
<b>Currency:</b>	Value between -922,337,203,685,477.5808 and 922,337,203,685,477.5807.
<b>Long:</b>	Contains an integer between -2,147,483,648 and 2,147,483,647.
<b>Single:</b>	Contains a floating point number with single precision between – 3.402823E38 and 3.402823E38
<b>Double:</b>	Contains a floating point number with double precision between – 1.79769313486232E308 and 1.79769313486232E308
<b>Date:</b>	Contains a number representing a date between 1 January 100 and 31 December 9999.
<b>String:</b>	Contains a string with a variable length composed of a maximum of around 2 billion characters.
<b>Object:</b>	Contains an object.

The conversion of types is managed by VBScript when it is clear. In the previous example if subtraction was used the result would be correct:

```
dim a,b,c
a=inputbox("First Number:")
b=inputbox("Second Number:")
c=a-b
MsgBox"Result "&c
```

```
dim a,b,c
a=inputbox("First Number:")
b=inputbox("Second Number:")
c=Cint(a)+Cint(b)
MsgBox"Result "&c
```

The dim instruction is used to state a variable, but this statement is not mandatory: the program works even without the "dim a,b,c" line. This makes programming even faster because it is not necessary to state the variables, they only need to be set.

When creating a complicated program it is advisable to use the "Option Explicit" command at the beginning of the program.

This command requires stating the variables and is useful if you make a mistake in writing the name of a variable. If I make a mistake with the name, the variable does not exist and an error is generated.

```
Option Explicit
dim a,b,c
a=inputbox("First Number:")
b=inputbox("Second Number:")
c=Cint(a)+Cint(b)
MsgBox"Result "&c
```

In choosing the name of a variable the following rules need to be taken into account:

It needs to start with a letter of the alphabet.

It cannot include periods and spaces.

It must not be composed of more than 255 characters.

There is no difference between upper and lower case letters.

There is also a non-mandatory rule: to give a non-logic name to a variable and thus a variable that must contain a date of birth could be called `dtDate_Of_Birth`, where `dt` indicates that it is a date type.

This is used to make programs easier to read.

## Operators

VBScript operators can be divided into types:

## Arithmetic Operators

		a=5 b=2	Result
+	Add	c=a+b	7
-	Subtract	c=a-b	3
*	Multiply	c=a*b	10
/	Divide	c=a/b	2,5
\	Whole Division	c=a\b	2
Mod	Module	c=a Mod b	1
^	Increase exponent	c=a^b	25
&	String chaining	c=a & b	52

For complex formulas, addition and subtraction from left to right have precedence.

## Comparison operators

## Comparison between two variables gives True or False

Not	Negation
And	Logical Conjunction
Or	Logical Disjunction

The following program is used to check arithmetic operators:

In the previous chapter the operator `+` was used to combine two strings, here the `&` sign is used. The two operators are equivalent but it is advisable to always use the `&` sign to better distinguish an addition operation.

To carry out operations under certain conditions the main command is IF. The syntax is as follows:

The following example uses the function `Month()`, which gives the month in a numeric form, and `Now()`, which gives the current date and time:

---

## Chapter 9

```
if month(Now())=6 then
MsgBox"It is June"
else
MsgBox"It is not June"
end if
```

It is also possible to create structures inside other structures, i.e. nested structures:

```
if month(Now())<=6 then
MsgBox "We are in the first half of the year <br>"
if month(Now())<=3 then
MsgBox "it is the first quarter."
else
MsgBox "it is the second quarter."
end if
else
MsgBox "We are in the second half of the year <br>"
if month(Now())<=9 then
MsgBox "it is the third quarter."
else
MsgBox "it is the fourth quarter."
end if
end if
```

Notice the importance of an indent formatting when using structures that are this complex. Another use of the IF instruction is the give as many conditions as possible:

```
if month(Now())<=3 then
MsgBox "We are in the first quarter."
elseif month(Now())<=6 then
MsgBox "We are in the second quarter."
elseif month(Now())<=9 then
MsgBox "We are in the third quarter."
else
MsgBox "We are in the fourth quarter."
end if
```

You can see that in this type of structure only one operation is carried out. Starting from the top and moving towards the bottom, at the first condition the corresponding operations is effected and the structure is left. If it was January all the conditions would have been true but only the first sentence would have been printed.

The logical operations NOT, AND and OR can be used to combine multiple conditions. When using structures with many choices based on the value of a parameter, you can use a structure with SELECT.

This is the same program as above but with a SELECT structure:

```
Select case month(Now())
case 1,2,3
MsgBox "We are in the first quarter."
case 4,5,6
MsgBox "We are in the second quarter."
case 7,8,9
```

In this structure the variable to check is set with the instruction "Select case Variable"., and then a list of possible values that the variable can assume with the instruction "case *value1*, *value2*, *value3*"; the operations to be carried out follow this instruction. In the example the variable is numeric, in the case of string variables the values are placed between quotation marks: case "*value1*", "*value2*", "*value3*".

## Structures for cycles

A cycle is used to repeat operations for a certain number of times or until a certain condition occurs. The FOR - NEXT cycle increments by a variable at each cycle. When the variable reaches an established value the cycle finishes.

```
Option Explicit
Dim i
For i=4 to 20
MsgBox i & "<br>"
next
```

The program prints the values from 4 to 20 in a column.  
Using the STEP parameter, I can count backwards and use different steps.

```
Option Explicit
Dim i
For i=20 to 4 step -2
MsgBox i & "<br>"
next
```

This program will display the numbers 20, 18, 16, 14, 12, 10, 8, 6, 4  
The FOR - EACH cycle is similar. This cycle is based on a set of objects and is repeated for each element of the set. In this example a vector is used. After being stated and filled, the following is displayed through a For Each cycle:

```
Option Explicit
Dim vector(5),element
vector(0)="Html"
vector(1)="Asp"
vector(2)="Php"
vector(3)="JavaScript"
vector(4)="VBScript"
for each vector element
MsgBox element & "<br>"
next
```

```
Option Explicit
dim StartTime, EndTime, count
count=0
StartTime=now()
EndTime=now()+1/(100000)
do While now()<=EndTime
count=count+1
loop
MsgBox "The cycle is repeated " & count & " times"
MsgBox " in 1 second"
```

```
Option Explicit
dim a
a=10
do
MsgBox "Test Until"
loop While a < 0
```

```
Option Explicit
dim cLines, Columns, Matrix(3,2)
matrix (1,1)=1
matrix (2,1)=2
matrix (3,1)=3
matrix (1,2)=4
matrix (2,2)=5
matrix (3,2)=6
for cLines=1 to 3
for cColumns=1 to 2
MsgBox mstrix(cLines,cColumns) & " "
next
MsgBox " <br>"
next
```

## Objects

Like in Visual Basic, in VBScript we also find the concept of object. An object is an entity which has properties, actions (methods) and generates events.

An item needs to be created to use an object, i.e. it needs to be stated and associated to a name.

To do this the `CreateObject` command is used. The syntax for creating an object is as follows:

Set object name= CreateObject( "type of object")

The objects (Active Objects) available in Creator Pro IV are listed below:..

## Creator Pro IV Active Objects

**Type: Global**

**Name: Project**

**Description:**

This object exports global function to modify the project

## Properties

ActiveItem	Sets/Gets active item indices
Methods	
ShowWindow	Displays the laser window if it is not visible
LoadProject(path)	Loads a new project and gives a TRUE value if successful.
ItemCount	Gives a number of project items
SelectActiveItem(id)	Activates the item set by the specified ID, gives the item index if successful, otherwise gives the value of -1
ShowActiveItem	Displays the page associated with the active item, gives TRUE if successful
ProcessActiveItem	Processes the active item (sends the data to the laser and launches engraving). Gives TRUE if successful.
GetActiveDocument	Gives the document associated with the active item.
UpdateViews	Updates the views

## Events

OnQueryStart	External start request (or software)
OnItemStart	Start Item is launched
OnItemStop	Start Item is stopped by the software or external stop.
OnItemEnd	Start Item ended
OnClose	Selects work mode for modify mode or closes the active project

Type: Global and Local  
Name: Document

Description: This object is a global shortcut to the first project document where the script is being executed. The Document object is particularly useful when it is necessary to customize a single document. It is possible to obtain a local document using the GetActiveDocument function for the project objects

Properties	None
------------	------

## Methods

Load(path)	Loads a document from the disk giving true if successful.
------------	---

**Save(path)** Saves a document from the disk giving true if successful.

Show	Shows a page associated with the document
------	---

GetObject(id)	Gives the document identified by the specified ID
---------------	---

Events	None
--------	------

Type: Local  
Name: String

Description: Strings are not global objects, but they can be obtained from the document using the `GetObject` function and specifying the ID of an existing string.

## Properties

Text	Sets/Gets the text object
------	---------------------------

Compression	Sets/Gets string compression
-------------	------------------------------

Spacing                  Sets/Gets sting spacing

CharHeight	Sets/Gets character height
------------	----------------------------

CharAngle      Sets/Gets character angle

CharShear      Sets/Gets character shear

Radius	Sets/Gets string radius on the circumference
--------	--

Angle	Sets/Gets start angle of the string on the circumference
-------	--

## Methods

Update	Updates the object while the modifications have effect
--------	--

Length	Gives the number of string characters
--------	---------------------------------------

Type: Local  
Name: Barcode

## Properties

## Methods

Length	Give the number of bar code characters
1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	
19	
20	
21	
22	
23	
24	
25	
26	
27	
28	
29	
30	
31	
32	
33	
34	
35	
36	
37	
38	
39	
40	
41	
42	
43	
44	
45	
46	
47	
48	
49	
50	
51	
52	
53	
54	
55	
56	
57	
58	
59	
60	
61	
62	
63	
64	
65	
66	
67	
68	
69	
70	
71	
72	
73	
74	
75	
76	
77	
78	
79	
80	
81	
82	
83	
84	
85	
86	
87	
88	
89	
90	
91	
92	
93	
94	
95	
96	
97	
98	
99	
100	

Type: Local  
Name: Datamatrix

## Properties

## Methods

Length	Gives the number of data matrix characters
--------	--

Type: Global  
Name: Axis

## Properties

## Methods

Move(index,position) Moves the selected mechanical axis to the specified position, gives TRUE if the command is correctly carried out

## Events

OnReachPosition(index) Requested position of the selected mechanical axis reached

**Name:** IoPort

## Methods

UncheckPort(port)	Stops the input test of the selected port
-------------------	---

## Events

Name: ComPort

## Properties

## Methods

Flush	Resets the port flush
-------	-----------------------

## Events





---

## **Chapter 10**

### Customizing Creator Pro IV

## Origin of the work area

The coordinates set in an engraving job, either plain or ring, have an origin as a reference. The origin is the point of coordinate 0.0 that the objects in the engraving area refer to. The point of origin is invisible but its position is indicated on the General page of the selected job.

By default, Creator Pro IV sets the center of the work area as the point of origin.

## Moving the origin of a work area

To modify the origin position, open the combo box related to the origin position and set the new position.

If you set the CUSTOM position, it is necessary to enter new X,Y coordinates which will set the new origin of the work area.


General	String	Data	Laser
<b>Main</b>			
Enable			<input checked="" type="checkbox"/>
Position X		0	
Position Y		0	
Width		90	
Height		17	
Mainaint Aspect			<input type="checkbox"/>
Angle		0	
Shear X		0	
Shear Y		0	
<b>Origin</b>			
Position		Center	
	<b>Fill</b>	Left Bottom	
Fill Type		Left Top	
Fill Angle		Right Top	
		Right Bottom	
		Center	



**NOTE:**

If a Custom origin is set, i.e. with coordinates set by the user, the grid will automatically be positioned in relation to the new origin.

The engraving program uses specifically made fonts to optimize the number of vectors forming the various letters for engraving applications. In addition, the program can convert True Type fonts installed in the system into its own format. If you want to install a particular type of True Type font for engraving, close all the open models and select "File" → "Fonts..." to open the font installation window.




The font menu can only be accessed if all engraving jobs are **CLOSED**

## Setting the focus

To set the type of focus currently used by the engraver select Laser Control. This window contains a list of available lenses, by selecting a lens its parameters are displayed.


The width of the work area is set by the focus length set in Laser Control.



- Open the Laser Control application by clicking twice on icon 1 in the Tray area
- Select the Correction page
- Open Combo Box 2 and set the focus used by the engraving laser

## Mechanical Axis Management

The engraver can manage three mechanical axes, namely X, Y and Z. The following figure shows how the axes are positioned (in black):



The program can define a minimum height (Min), a maximum height (Max) and a zero height (Zero) for each axis. Each axis can be reversed.


## Linear axes

The Z axis in the figure has a zero height which is different from null and is reversed. The X and Y axes (mechanical) coincide with the x and y axes (logic).

In this example, the logic height  $z + 0$  mm coincides with the focus height from the working plain. A height  $z > 0$  mm would mean that the focus position is over the working plain.

## Rotary axis

Axis management is completely independent from the axis itself. This is because the engraving program can be configured to manage an angular axis simply by setting the Z axis to "zero" at the center of the ring and configuring the rotary axis conversion factor in order to correctly convert the angular positions (e.g. "steps per revolution"/ 360 = sexagesimal degrees). In the following example, axis x is a rotary axis.




## Connecting an axis (Step Controller)

The DSP board is able to drive up to the independent step type axes. The board uses the following signals to control each axis:

- Step:** Open collector output, generates the steps for the step motor controller. The generated frequency is based on the set movement speed, the duty-cycle is equal to 50%.
- Dir:** Open collector output, direction signal.
- Break** Open collector output, brake unlock signal
- Zero:** Opto-isolated input, mechanical zero detection input.

The following diagram shows how to connect an axis driven by a step controller to the DSP board.




---

## **Chapter 11**

### DSP board management


## Laser Control

The "DSP" control program is used to set laser engraving parameters for the various applications. Each set of parameters is logically grouped on a page to facilitate access. The program can be accessed from the "Control Panel" via the "DSP Control" icon or from the yellow icon depicting laser emission present in the "Tray Area" (the area in the lower right on the Windows bar) of the Windows shell as shown in the figure below.



Installation of the program takes place automatically when the **Creator Pro IV** graphic editor is installed as described below.

## "Scanner" parameters



This page is used to set the scanner speed when the laser is off (*Jump Speed*) and the waiting times for adjusting the engraving quality with respect to running times.



### NOTE:

See **Setting Waits** for the correct wait settings.

ÖSTLING Markiersysteme GmbH




---

## Chapter 11

- **Level – Min:**  
Minimum current level expressed in V. Corresponding to 0% power.
- **Level – Max:**  
Maximum current level expressed in V. Corresponding to 100% power.
- **Level - Ramp:**  
Time expressed in ms required to complete the ramp from minimum to maximum level.
- **FPK – Delay:**  
First pulse delay expressed in us.
- **FPK – Level:**  
First pulse level expressed in V.
- **Waits – Shot time:**  
Last pulse shpt time expressed in us.
- **Waits – Power change:**  
Warm up time, expressed in ms, i.e. the waiting time between the end of the level ramp and start of engraving. The waiting time allows the laser to stabilize before the process.
- **Waits – Stand by:**  
Stand-by time, expressed in s, i.e. the waiting time between the end of engraving and the level ramp resetting the minimum value (stand-by value). This waiting time allows the laser to remain stable between two close engraving processes, consequently saving process time.

### “Correction” parameters



This page is used to set the optical correction required to recover the distortion of mirrors and lens.  
The parameters are:

- **X/Y:**  
Value, expressed in degrees, indicating the curvature to be applied to each axis.
- **Scale X/Y:**  
Scale, expressed in %, to be applied to each axis.
- **Reverse X/Y axe:**  
To reverse the relative axis.
- **Swap X-Y axes:**  
To swap X axis and Y axis

The three axis reverse parameters are used to direct the engraving field in the four angular positions:: 0°, 90°, 180° and 270° as described below:

- *0° rotation* : None.
- *90° rotation* : Reverse X + Swap X-Y.
- *180° rotation* : Reverse X + Reverse Y.
- *270° rotation* : Reverse Y + Swap X-Y.



**NOTE:**

See **Foundations on engraving and optical correction** for a better understanding of optical correction.

ÖSTLING Markiersysteme GmbH




---

## Chapter 11

- **Speed:**  
Pointer limit processing speed, expressed in Kspots/s.
- **OfsX/Y:**  
Alignment offset, expressed in points per respective axis.
- **ScaleX/Y:**  
Limit scaling in relation to engraving, expressed in % on the respective axes.

## “Inputs” parameters



These two pages are used to set laser input signal time and delay in relation to engraving. The parameters are:

- **Inputs – Start Time:**  
To set the minimum start engraving signal duration, expressed in ms.
- **Inputs – Start Delay:**  
To set the delay (in ms) between start engraving signal acceptance and start of engraving process.
- **Inputs – Stop Time:**  
To set the minimum stop engraving signal duration, expressed in ms.

ÖSTLING Markiersysteme GmbH



---

## Chapter 11

- **Outputs – Busy Advance:**  
Advance, expressed in ms, of the busy signal (engraving in progress) in relation to the start of process. This parameter can be useful when the signal is used to open an electromechanical shutter.
- **Outputs – Busy Delay:**  
Delay, expressed in ms, of the busy signal in relation to the end of the process.
- **Outputs – End Delay:**  
Duration of the end of engraving signal.

### **“X/Y/Z Axe” parameters**

**Laser Control**

Scanner   Laser   Correction   Limits   Inputs

Outputs   X Axis   Y Axis   Z Axis

Conversion   Enable ☐

100.00 = 1.00 step = unit

Motor

Break release: 250 ms

Ramp time: 250 ms

Start speed: 5 unit/s

Speed: 30 unit/s

Limits

Min: -1000 unit

Max: 1000 unit

Zero: 0 unit

Reverse axis ☐

Ok   Apply   Cancel

This page is used to set the parameters related to the three mechanical axes controlled by step motors. The parameters are:

- **Enable:**  
To allow axis use.
- **Conversion:**  
These two parameters establish the correspondence between motor steps and millimeters of shift.
- **Motor – Break release:**  
Electromechanical brake release time, expressed in ms. This is the time which passes between brake release signal activation and mechanical movement start.
- **Motor – Ramp Time:**  
This is the time, expressed in ms, employed by the acceleration ramp to go from minimum speed (Start speed) to working speed (Speed).
- **Motor – Start speed:**  
Minimum motor revolution speed, expressed in mm/s.
- **Motor – Speed:**  
Motor revolution speed at the end of acceleration, expressed in mm/s.
- **Limits – Min:**  
Minimum motor position limit, expressed in mm.
- **Limits – Max:**  
Maximum motor position limit, expressed in mm.
- **Limits – Zero:**  
Position (in mm) of the axis logic zero in relation to the mechanical zero. Each movement of the axis is considered in relation to the logic zero. Conversely, axis resetting locates the mechanical zero.
- **Limits – Reverse Axe:**  
To reverse axis logic.



**NOTE:**

See **Mechanical Axis Management** for additional information on axis use and parameter settings.


---

## **Chapter 12**

### **Engraving and optical correction**

## Foundations of engraving and optical correction


The scanning head used for laser engraving employs two electrical drives to set the angular position of the two mirrors and deflect the beam along the two directions X and Y. A simplified diagram is shown below (**Fig. 1**):



**Figure 1: Scanning head**

## Distortion

The picture projected on the engraving surface by the two mirrors is deformed due to the different length of the optical paths for the different angles. Observe **Fig. 2**. The point on the plain does not follow a straight line parallel to the x axis as angle  $J_x$  varies, instead it follows a trajectory which is similar to a parabola distancing the hypothetical line according to the two angles  $J_x$  and  $J_y$ .



**Figure 2: Projection on plain**

$$\begin{cases} x = f \cdot \tan(\mathbf{J}_x) \\ y = (d + h) \cdot \tan(\mathbf{J}_y) = \left[ d + f \cdot \sqrt{1 + \tan^2(\mathbf{J}_x)} \right] \cdot \tan(\mathbf{J}_y) = \left( d + \frac{f}{\cos(\mathbf{J}_x)} \right) \cdot \tan(\mathbf{J}_y) \cong f \cdot \frac{\tan(\mathbf{J}_y)}{\cos(\mathbf{J}_x)} \end{cases}$$
$$\Delta y = f \cdot \frac{\tan(\mathbf{J}_y)}{\cos(\mathbf{J}_x)} - f \cdot \tan(\mathbf{J}_y) = f \cdot \tan(\mathbf{J}_y) \cdot \left( \frac{1}{\cos(\mathbf{J}_x)} - 1 \right)$$
$$\Delta \mathbf{J}_y = \tan^{-1} \left( \frac{\Delta y}{f} \right) = \tan^{-1} \left[ \tan(\mathbf{J}_y) \cdot \left( \frac{1}{\cos(\mathbf{J}_x)} - 1 \right) \right]$$

The lenses used for scanner heads (e.g. RODENSTOCK f-theta objective), in addition to focusing on the work plain, apply a deformation ,called barrel distortion, to eliminate the dependency from the tangent.

The use of these lenses could simplify the task of the software by eliminating tangent distortions.




---

## **Chapter 13**

### Practice exercises


### Exercise 1 -Project for engraving on different levels

The figure below shows a job which entails movement of the three mechanical axes for engraving the piece in three different positions.



The proposed exercise involves creating a project with a sequence of three different engraving items on the plain (laser) separated by the axis movement function.

- ▲ ▼



Set the shift value along axes X, Y, Z for each “Axis Shift” function in the project sequence.



---

## **Chapter 14**

### **End user license agreement**

**Important - Read carefully:**

This End User License Agreement is a legal agreement between you (either an individual or a single entity) and ÖSTLING Markiersysteme GmbH (hereinafter "ÖSTLING") for a ÖSTLING software product, including software, the associated media, any printed materials and any "online" or electronic documentation (hereinafter generally denominated "software product").

By installing, copying or otherwise using the software product, you agree to be bound by the terms of this License Agreement.

## Software product license

The software product is protected by copyright laws and international copyright treaties, as well as any other intellectual property laws and treaties. The software product is licensed not sold.

## 1. Grant of license

## Software.

You may install and use one copy of the software product on a single computer, or in place of a previous version destined for the same operative system. The original user of the computer on which the software is installed has the right to create a second copy for his own exclusive use on a home computer or portable computer.

### Storage/Network use.

You may also store or install a copy of the software product on a storage medium, such as a network server, to the extent that such is used exclusively for installing or using the software product on your internal network. However, you must acquire and dedicate a license for the software program for each computer on which the software program is installed or to which it is distributed. A license for the software program may not be shared or used concurrently on different computers.

## License package.

If you acquired the present License Agreement as part of a ÖSTLING license package you will be entitled to create other copies of the software product in the authorized number according to the printed copy of the present License Agreement. You can use each copy in the manner indicated above. You also are entitled to produce a corresponding number of copies for use on a home computer or portable computer in conformity with the above mentioned clauses.

## 2. Description of other rights and limitations

### Limitations on reverse engineering, decompilation and disassembly.

You may not reverse engineer, decompile or disassemble the software product, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

### Separation of components.

The software program is licensed as a single product. Its component parts may not be separated for use on more than one computer.

## Software transfer.

You may permanently transfer all of your rights under this Agreement only as part of a sale or transfer, provided that you retain no copies, transfer all of the software product (including all component parts, the media and the printed materials, any upgrades, The Agreement and, if applicable, the Certificate(s) of Authenticity and the recipient agrees to the terms of this Agreement. If this software product is an upgrade, any transfer must include all prior versions of the software product.

Without prejudice to other rights, ÖSTLING may terminate this Agreement if you fail to comply with the terms and conditions of the Agreement. In such event, you must destroy all copies of the software product and all of its component parts.

If the software product is an upgrade from another product, whether from ÖSTLING or another supplier, you may use or transfer the software product only in conjunction with that upgraded product, unless you destroy the upgraded product. If the software product is an upgrade of a ÖSTLING product, you may use that upgraded product only in accordance with this Agreement. If the software product is an upgrade of a component of a package of software programs which you licensed as a single product, the software product may be used and transferred only as part of that single product package and may not be separated for use on more than one computer.

All title and copyrights in and to the software product (including but not limited to any images, photographs, animations, video, audio, music, text and "applets", incorporated into the software product), the accompanying printed material, and any copies of the software product, are owned by ÖSTLING. The software product is protected by copyright laws and international treaty provisions. Therefore you must treat the software product as any other type of material covered by copyright, with the exclusion that you either (a) create a single backup copy of the software product to be used exclusively for backup and file requirements; or (b) install the software product on a single computer if the original is kept for backup and file requirements. You may not copy the printed materials accompanying the software product.

You may receive the software product in more than one medium. Regardless of the type or size of the medium you receive, you may only use one medium that is appropriate for your single computer. You may not use or install the other medium on another computer. You may not loan, rent, lease or otherwise transfer the other medium to another user, except as part of a permanent transfer (as provided above) of the software product.

